Installation manual

Fibre ring (V0191) in tiled pools WV15 flat (for the tiler)



The tiler can treat the mounting ring in the same way as tiles. The tile adhesive and cement used for tiles can also be used for the mounting ring

Place mounting ring step-by-step plan



1. The pot is cast into the concrete of the pool wall.



2. Tile partially over the recessed housing.



3. Place the ring on the recessed housing and screw it to recessed housing.



4. Mark the mounting ring with a marker.



5. Remove the ring from the wall so that only the outline of the ring is visible.



6. Remove the tiles, grind the tiles to the desired shape and stick them back.




7. Fill the edge with cement/tile adhesive and screw the ring back onto the recessed housing so that it is flush with the surface of the tiles. The ring can then be added flush with the other tiles.



8. The installer can then install the pool light.

End result: a 100% flat lamp





Installation manual

Fibre ring (V0191) in tiled pools WV15 flat (for the tiler)



Step-by-step plan for placing an underwater floodlight



1. Loosen the screws of the mounting ring




2. Cut off the plastic edge of the mounting ring.




3. This is what the ring looks like after the plastic has been removed.




4. Place the pool light and tighten the screws.



End result: a 100% flat lamp







The Netherlands	France	Germany
WaterVision BV	WaterVision SARL	WaterVision GmbH
Vlierberg 9	130 Boulevard de la Liberté	Boschstraße 16
NL-3755 BS Eemnes	FR-59000 Lille	D-47533 Kleve
I. www.watervision.nl	I. www.watervision.fr	I. www.watervision.de
E. info@watervision.nl	E. info@watervision.fr	E. info@watervision.de
T. +31 (0)35 5387959	T. +33 (0)3 20572544	T. +49 (0)2821 8944850
F. +31 (0)35 5330551	F. +33 (0)3 20540324	F. +49 (0)2821 8944859